## Honeywell

# **Model MS3 DC-DC**



# Miniature Displacement Transducer

#### **DESCRIPTION**

Model MS3 (free unguided armature) dc-dc miniature displacement transducer is ideally suited for multi-point applications with space constraints and provide a cost-effective alternative

to larger, more expensive units. This model is compatible with dc data logging equipment used for taking readings from strain gages or other dc operated transducers.

#### **FEATURES**

- Miniature design
- Cost efficient
- 0.25 % non-linearity
- Stainless steel construction
- ±0.1 in to ±0.4 in range
- Infinite resolution
- Single or dual supply wiring (field selectable)
- Free unguided armature
- Not RoHS compliant

## **Model MS3 DC-DC**

## PERFORMANCE SPECIFICATIONS

Characteristic	Measure
Stroke range	±2,54 mm to 10,16 mm [±0.1 in to 0.4 in]
Non-linearity (max.)	±0.25 % full scale
Output impedance	2 ohm
Output load (min.)	2000 ohm
Output sensitivity	±5 Vdc or 0 Vdc to 10 Vdc (field selectable)
Resolution	Infinite

## **ENVIRONMENTAL SPECIFICATIONS**

Characteristic	Measure
Temperature, operating	-50 °C to 70 °C [-58 °F to 158 °F]
Temperature effect, zero (max.)	0.006 % full scale/°F
Temperature effect, span (max.)	0.017 % full scale/°F

### **ELECTRICAL SPECIFICATIONS**

Characteristic	Measure	
Element type	dc-dc displacement transducer	
Power supply, single	24 Vdc to 40 Vdc @ 30 mA	
Power supply, dual	±12 Vdc to ±20 Vdc @ 30 mA	
Electrical termination	Multiconductor shielded cable (1.83 m [6 ft])	

### **MECHANICAL SPECIFICATIONS**

Characteristic	Measure
Case material	Stainless steel
Probe material	Stainless steel
Armature type	Free unguided
Probe thread	M3 x 0.5
Weight	73,5 g [2.6 oz]

## **RANGE CODES**


Range Code	Available ranges
НМ	±2,54 mm [±0.1 in]
HN	±5,08 mm [±0.2 in]
HF	±7,62 mm [±0.3 in]
HG	±10,16 mm [±0.4 in]

## **OPTION CODES**


Range Code	Many range/option combinations are available in our quick-ship and fast-track manufacture programs. Please see http://sensing.honeywell.com/TMsensor-ship for updated listings.	
Stroke ranges	±25,4 mm to 101,6 mm [±0.1 in to 4 in]	
Electrical termination	Multiconductor shielded cable (1.83 m [6 ft]) 6a. Bendix PTIH-10-6P right angle Bendix	
Electrical cable orientation	Ra. Right angle	
Mounting threads	13a. 1/2-20 UNF 13f. 3/8-32 UNF	
Improved linearity	L10. 0.1 % on some models	

## Miniature Displacement Transducer

## **MOUNTING DIMENSIONS**




### **TYPICAL SYSTEM DIAGRAM**



#### **WIRING CODES**

Wire color	Dual supply	Single supply (floating)*	Outputs
Red	12 V to 20 V input	24 V to 40 V input	
Blue	-12 V to -20 V input	Supply negative	
Black	OV, I/P, O/P com- mon		
Yellow			0 V to 10 V
Green			±5 Vdc

<sup>\*</sup> Output common floats at voltage source/2



## Model MS3 DC-DC

#### **NOTES**

 GM-A should not be used with an amplified displacement transducer unless using an external power supply to power the displacement transducer.

## Miniature Displacement Transducer

Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.


Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

For more information about Sensing and Control products, visit www.honeywell.com/sensing or call +1-815-235-6847 Email inquiries to info.sc@honeywell.com



• DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.



- The information presented in this catalogue is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

Sensing and Control
Automation and Control Solutions
Honeywell
1985 Douglas Drive North
Golden Valley, MN 55422 USA
+1-815-235-6847

Honeywell